



FVC-90(Viscocare-HA90F)

Multifunctional thickener

that improves emulsification and stability of finished products



FVC-90(Viscocare-HA90F)

INCI/CTFA Name	Hydroxyethyl acrylate / Sodium acryloyl dimethyl taurate copolymer
Appearance	White Powder
Solid Content	90% min.
pH @ 1.5% aqueous	5.0~6.5
Viscosity @ 1.5% aqueous	70,000 ~ 100,000 mPas
Shelf life	36 Months
Recommended usage	0.2~3%
China regulatory	Listed in IECIC, NMPA registered



Product Line-up



	No Oil	No Oil	C13~14 Isoparaffin (Light)	Isohexadecane (Light)	Polyisobutene (Light)	Hydrogenated Polydecene (Smooth)	Squalane (Smooth)
Acrylate (Fresh)	FVC-90 (Viscocare- HA50F)	Coming up E.O. Free FVC-90		FVC-E50 (Viscocare- EG50F)	Coming up E.O. Free FVC-E50		Coming up Mineral Oil Free FVC-N40
AMPS (Soft)							
Polyacrylate-13 (Rich)						FVC-400 (Viscocare- P400F)	
Acrylamide (Rich)			FVC-P50 (Viscocare- PA50F)				

Contents

- Product Features
- Self Phase Inversion-able Emulsion Thickener
- Emulsification Power
- Thickening Capability
 - Per Thickener Concentration
 - Per pH Effect
 - Per existence of Electrolyte
 - Per existence of Acid
- Compatibility with Solvents
- Sensory
- Formulation Tips



Product Features



- It can be used on water or oil in the form of a powder that is neutralized in advance and easy to use, and can be applicable at room temperature production
- Viscosity can be formed under conditions of pH 3 – 11.
- Excellent thickener, stabilizer, emulsifier even at low usage
- Emulsification capacity for various oils
- Stable structure provides excellent incremental effects in DHA, AHA, H₂O₂, Solvent, etc
- It is possible to form a formulation that is easy to pick-up with a smooth use.
- Residual solvent free (Benzene, n-butanol, Ethyl Acetate, Butyl Acetate)




Emulsification Power

	*MCT 15%	JOJOBA OIL 15%	*LP 15%	*DC 245 10%	*CEH 15%
Cream-Gel (< 100,000 m.Pas) FVC-90(Viscocare-HA90F) (2%)	Stable	Stable	Stable	Stable	Stable
Cream-Gel (< 20,000 m.Pas) FVC-90(Viscocare-HA90F) (0.6%)	Stable	Stable	Stable	Stable	Stable
Remark	Stability measurement conditions: 3-month, 45°C Composition of formula to measure the stability : Thickener / Oil / Water				

1. MCT = Caprylic / Capric Triglyceride, 2. LP = Liquid Paraffin 3. DC 245 = Cyclopentasiloxane 4. CEH = Cetyl Ethyl Hexanoate



Thickening Capability Per concentration Change



➤ Objectives

- How much it can increase viscosity at diverse concentration of FVC-90(Viscocare-HA90F) in DI water and it compares with benchmark.


➤ Methods

- Prepare solution of 1.0 – 3.0 % concentration of FVC-90(Viscocare HA90F).
- Using automatic agitation in low concentration
- In high concentration, using manual agitation
- RVT Viscometer

➤ Result

- Viscosity profile of FVC-90(Viscocare-HA90F) shows its capability to increase the viscosity when its concentration in DI water versus concentration is very similar to the benchmark one

Thickening capability over a wide pH range



➤ Objectives

- How much it can increase viscosity in pH conditions from acid to base. It also compares with benchmark.

➤ Methods


- Prepare 2% FVC-90(Viscoscare-HA90F) & benchmark in DI Water, respectively.
- Add Lactic acid or 10% NaOH solution to make a designed pH in 2% FVC-90(Viscoscare-HA90F) solution and benchmark one, respectively.

➤ Result

- Viscosity profile is similar to a benchmark's one. We confirm 2% FVC-90(Viscoscare-HA90F) solution in DI water is generating the viscosity between pH 3 and 10



Thickening capability in presence of electrolytes



➤ Objectives

- How much it is resisting to electrolyte when it generate viscosity.

➤ Methods


- Prepare solution of FVC-90(Viscocare-HA90F), NaCl with DI water.
- For each sample increase FVC-90(Viscocare-HA90F) by 1 % at 2% to 5%. NaCl remains at 0.6% for each sample. Mix DI water to fulfill 100%.
- Measure the viscosity.

➤ Result

- Viscosity profile shows similar pattern. When FVC-90(Viscocare-HA90F) concentration is more than 3%, its viscosity is higher than that by benchmark.



Thickening capability in presence of Glycolic acid



➤ Objectives

- How much it is resisting to glycolic acid when it generate viscosity.


➤ Methods

- Prepare solution of FVC-90(Viscocare-HA90F), Glycolic acid with DI water.
- For each sample increase FVC-90(Viscocare-HA90F), by 0.5 % at 2% to 5%. Glycolic acid remains at 3 % for each sample. Mix DI water to fulfill 100%.
- Mix well
- Measure the viscosity.

➤ Result

- Viscosity profile is better than a benchmark's one. When concentration of FVC-90(Viscocare-HA90F), is more than 3%, its viscosity is higher than that by benchmark. Its pattern is similar to benchmark.

Compatibility with Solvents



➤ Objectives

- How it works to generate viscosity with diverse solvents in use personal care/ cosmetics.

➤ Methods

- Prepare 2% FVC-90(Viscoscare-HA90F) solution, 48% DI Water and 50 % solvent of Glycerine, 1,3-Butylene glycol, ethanol, propylene glycol, respectively.
- Prepare 2% FVC-90(Viscoscare-HA90F) solution, 88% DI Water and 10 % Silicone DC345.
- Measure the viscosity to use Brookfield RVT , 5rpm, spindle no 6

➤ Result

- Viscosity is similar to a benchmark's one.


Sensory

FVC-90(Viscocare-HA90F) delivers following sensory.

- A soft texture
- Even if the viscosity is high, it's easy to pick-up
- Refreshing and smooth feel
- Fast absorption for non-sticky use

Absorption
Slow

Absorption
Fast



Formulation Tips



Transparent (Availability) Products – Toner, Gel, Sheet Mask

- No use of additional oil.
- Solubilizer (Tween20, PG10-Laurate, Caprylic Capric Glucose) uses less than 1%.
- Need to add moisturizer (Glycerine, BG, Propanediol).

Cream gel (translucent) products – Moisturizing cream, sleeping pack

- Can be added to oil or water phase.
- Adding to the oil phase makes it easy to disperse the thickener for viscosity generation.

Emulsified (milky) products – lotion, cream

- It is recommended to add the polymer after the emulsification stage and before adding the fragrance and preservatives.
- If added before emulsification, it is recommended to be added to oil phase to facilitate production.

Make-up products - tone-up cream, base makeup

- It is recommended to put the thickener in the last stage of emulsification.
- Inorganic pigment recommends the use of products dispersed in oil or silicon (O/W formulation)



Thank you for your attention

If you have further questions or requests, please contact following
Sam Jeon (ysjeon@ftckorea.com)
Ed Kim (twkim@ftckorea.com)

- Information in this introduction is a referential purpose.
- To the extent permitted by applicable law, the FTC Korea disclaims any liability relating to the use or reliance of your information. The FTC Korea makes no warranty or statement, express or implied, in relation to the utility. Denies an implied warranty of the integrity and merchantability of the information and suitability for a particular purpose. The FTC Korea disclaims liability for any accidental or consequential damages.
- The experimental results included in this catalog are FTC Korea internal experimental data and must be checked by the user when applied to the product. The results are not responsible to the FTC Korea.